Digital Signal Processing: COSC360

Jordan Hanson January 19, 2022

Whittier College Department of Physics and Astronomy

Unit 2.1 Outline

- 1. Introduction: Types of filters (reading: ch. 3, ch. 5)
 - Butterworth
 - Bessel
 - · Chebyshev
- 2. LTI systems and their properties (reading: ch. 5)
- 3. Convolution (reading: ch. 7)
 - · Implementation with FFT
 - Impulse and step response

Future lectures will cover:

- 1. SNR of filtered signals: SNR
- 2. Common filter kernels (moving average, windows)
- 3. Recursive filters
- 4. FIR and IIR definitions

Chapter 3 lists three types of anti-aliasing filters: Butterworth, Bessel, and Chebyshev. Filters are examples of linear, time-invariant (LTI) devices




Figure 1: A linear, time-invariant system has special properties encapsulated by the *convolution operation*.




Figure 2: Comparison of transfer function magnitudes.




Figure 3: Comparison of transfer function step responses.




Figure 4: Comparison of transfer function pulse responses.

The single-pole Butterworth transfer functions are derived from the single-pole RC filter circuit:

$$H_{LP}(\omega) = \frac{\omega_0}{\omega_0 + j\omega}$$

$$H_{HP}(\omega) = \frac{\omega}{\omega - i\omega_0}$$
(2)

$$H_{HP}(\omega) = \frac{\omega}{\omega - j\omega_0} \tag{2}$$

- What frequency causes a singularity in the transfer functions?
- · What is the phase and group delay of this filter?

General expression for the transfer function of Butterworth filter (low-pass):

$$|H_{LP}(\omega)| = \frac{G_0}{\sqrt{1 + \left(\frac{j\omega}{\omega_0}\right)^{2n}}} \tag{3}$$

The integer n is the number of poles. G_0 is the gain, and ω_0 is the corner or cutoff frequency.

- · Can we plot the poles in the complex plane?
- · What is the phase and group delay of this filter?




Figure 5: Gain of butterworth filters with n poles.

The n-th order low-pass Bessel filter transfer function is a ratio of reverse Bessel polynomials:

$$H(\omega) = \frac{\theta_n(0)}{\theta_n(j\omega/\omega_0)} \tag{4}$$

where the reverse Bessel polynomials $\theta_n(x)$ are given by

$$\theta_n(x) = \sum_{k=0}^n \frac{(n+k)!}{(n-k)!k!} \frac{x^{n-k}}{2^k}$$
 (5)

- What is θ_3 ?
- · How do we turn this into a high-pass filter?
- · What are the pole locations of the 3rd-order Bessel filter?

The n-th order low-pass Chebyshev filter transfer function is

$$|H(\omega)| = \frac{1}{\sqrt{1 + \epsilon^2 T_n^2(\omega/\omega_0)}} \tag{6}$$

where the Chebyshev polynomials $T_n(x)$ are given by

$$T_n(x) = \cos(n\cos^{-1}(x)) \quad |x| < 1$$
 (7)

$$T_n(x) = \cosh(n\cosh^{-1}(x)) \quad x \ge 1$$
 (8)

$$T_n(x) = (-1)^n \cosh(n \cosh^{-1}(-x)) \quad x \le 1$$
 (9)

- Can we plot $T_2(x)$ in Octave?
- Pole locations are interesting (next slide).




Figure 6: Eight-pole Chebyshev filter in the complex plane. The poles form an ellipse, due to the trigonometric nature of the definition of Chebyshev polynomials.

In the octave signal package, we can access the transfer functions of these filters:

```
pkg load signal;
[b1,a1] = butter(n,omega); %(e.g. include "high")
[b2,a2] = besself(n,omega);
[b3,a3] = cheby1(n,rp,omega); %rp pass-band ripple
x = (...); %data
y = filter(b1,a1,x);
```

Use **help** function on these for more information. The **filter** function is using the pole-zero information stored in the coefficients *a* and *b* to apply the transfer function to the data (more later).

programming example

Introduction: Types of filters, Octave

If you have the **signal** package, you can specify a n-th order butterworth filter with **butter** as above. Otherwise, you can write a small function using Eq. 3 for the digital response.

- 1. Create a white-noise sample (randn) of 10⁴ samples. You can also specify a time vector of the same size.
- 2. Plot the spectrum of this noise using fft¹.
- 3. **Filter** the noise with a 2nd-order low-pass butterworth filter, at a cutoff frequency of $0.2 f_s$. Either use the **filter** function and fft, or multiply in the Fourier domain.
- 4. Filter the noise with a 2nd-order high-pass butterworth filter, at a cutoff frequency of $0.4 f_s$.
- 5. Now do (3) then (4), and plot the spectrum. Repeat for (4) then (3). Do you see the same spectrum?

¹See the **Aliasing.m** script in Unit 1

Filters are LTI systems. Let's review the properties of LTI systems:

- 1. Continuous vs. discrete
- 2. Scaling property
- 3. Distributive property
- 4. Time-invariance (also causality)
- 5. Commutative property
- 6. Combination of properties




Figure 7: A continuous LTI system response to continuous data, and a discrete LTI system response to discrete data. All properties should hold both cases.




Figure 8: Scaling: If the data is scaled by a real constant, the output should be scaled by a real constant.




Figure 9: Distributive property: the LTI system should respond to each signal separately.




Figure 10: Time-invariance: the LTI system should respond when the signal arrives, independent of global time. Also, the filter should not respond *before* the signal arrives (causality).




Figure 11: Commutative property: the LTI system should not depend on the existence of previous systems.




Figure 12: Combination of properties: an LTI system may be built from a combination of LTI systems.

Suppose A(x), B(x), C(x), D(x), and E(x) represent operators of LTI systems. What is the formula for a) y_1 , b) y_2 and c) y_3 ? What is the the Fourier transform of the simplest output?

The **convolution** operator has all of the necessary properties of the LTI system operator. The convolution of data streams x_1 and x_2 :

```
x 1 = (...); %data1
x 2 = (...); %data2
v 1 = fft(x 1);
v = fft(x = 2);
Z 1 = v 1.*v 2;
result = real(ifft(Z 1));
Or, in one line:
result = real(ifft(fft(x 1).*fft(x 2)));
Or.
result = conv(x 1, x 2); %Pay attention to size
```

The built-in Octave function **conv** for convolution produces two sizes, the full and the half-size.

```
x 1 = (...); %data
x 2 = (...); %data
v = conv(x 1, x 2);
size(v)
size(x 1)
size(x 2)
Special case of conv:
y = conv(x 1, x 2, "same"); %default; "full"
size(y)
size(x 1)
size(x 2)
```

The unit-impulse function δ is given by the identity:

$$x[n] \circ \delta[n] = x[n] \tag{10}$$

Try the following in Octave:

```
clear; home; close;
function out = gauspulse(t,amp,mu,sigma)
    out = amp*exp(-0.5*((t-mu)/sigma).^2);
endfunction
t = linspace(0,10,10000);
r = zeros(size(t));
r(1000) = 1/sqrt(2); r(2500) = -1/sqrt(2);
x = gauspulse(t, 1.0, 5.0, 0.2);
y = conv(r,x,"same");
plot(t,x,'color','black'); hold on;
plot(t,v,'color','blue');
sum(x.^2)/sum(v.^2)
```

- 1. Does the output make sense? Why?
- Exercise: Write Octave code that produces a sine wave. Now
 write a transfer function that causes total destructive
 interferance. When the sine wave is convolved with the transfer
 function, the output should be a DC level.
- 3. Exercise: Write a transfer function that doubles the amplitude.
- 4. **Thought experiment**: Could you write a transfer function that would double the frequency? Why or why not?

Normal distribution

Transfer Function

The convolution of a **transfer function** with an input signal to an LTI system produces the output signal. Mathematically, if h(t) is the transfer function, i(t) is the input signal, and o(t) is the output:

$$o(t) = h(t) \circ i(t) = \int_{-\infty}^{\infty} h(\tau)i(t-\tau)d\tau$$
 (11)

The convolution theorem also states that

$$o(t) = F^{-1}\{H(\omega)I(\omega)\}\tag{12}$$

Consider the following function:

$$h(t) = \omega_0 \exp(-\omega_0 t) \quad t \ge 0 \tag{13}$$

$$h(t) = 0 \quad t < 0 \tag{14}$$

- 1. What is the Fourier transform of h(t)?
- 2. Do you recognize this transfer function?
- 3. Write an Octave function that digitizes the time-dependent version of this transfer function.
- 4. Convolve with a sine wave of frequency $2\omega_0$. What happens?

Let's repeat the exercise, but for *high-pass* filtering. Without knowing the time-domain equation for the response, how can we do this with transfer functions?

- 1. Consider taking the unit impulse signal *minus* the low-pass component. How do you add two transfer functions to get this to happen?
- 2. Convolve with a sine wave of a frequency less than the cutoff of the high-pass filter. Do you see attenuation?

Normalization of filters: (1) high-pass filters should have no gain at DC (f=0 Hz), and (2) Filters should conserve energy (amplitude squared) in the pass-band. Let's ensure this by requiring

```
sum(h) = 1.0; %High-pass case

sym(h.^2) = 1.0; %Think about this one more...
```




Figure 13: Chapter 7: low-pass transfer functions, digitized. Notice that they are wide, and positive.




Figure 14: Chapter 7: high-pass transfer functions, digitized. Notice that they resemble the unit impluse minus a low-pass filter transfer function.




Figure 15: Chapter 7: causal filters do not anticipate the signal.




Figure 16: Chapter 7: the phase of the transfer function can be related to the group delay. What is meant by *linear* phase, versus zero phase, in terms of group delay?

LTI Systems Application: RF filters

and Johnson-Nyquist Noise

LTI Systems Application: RF filters and Johnson-Nyquist Noise

Johnson-Nyquist noise is the presence of random voltages across a circuit due to electron thermal fluctuations. Let k_B be Boltzmann's constant², Δf be some bandwidth $f_{max} - f_{min}$ in frequency, R be the resistance in Ohms at a temperature T in Kelvin. The variance of the noise is

$$v_{rms}^2 = 4k_B T R \Delta f \tag{15}$$

Let's write an Octave script to generate normally distributed noise with this *variance*. Make sure to define $\Delta f = f_{max} - f_{min}$. Next, define a cosine or sine with frequency that is inside this bandwidth, and add it to the noise. $SNR \approx 10$.

- 1. What happens to the SNR when you begin to filter the total signal, such that we keep the sinusoid intact?
- 2. Plot the SNR vs. cutoff frequency in your filter as you vary it.

 $^{^{2}}$ $k_{B} = 1.38 \times 10^{-23} \text{ m}^{2} \text{ kg s}^{-2} \text{ K}^{-1}.$

Special Topic: Impulse response of

RF antennas

Special Topic: Impulse response of RF antennas

A paper on RF antenna response for UHE neutrino research: https://doi.org/10.1016/j.astropartphys.2014.09.002